

No Annual Factory Re-certification Required

MINI LITE

AS/NZS 1891.4 stipulates that users of Type 2 Fall Arresters must abide by the manufacturer's instructions on how to use and inspect their fall arresters.

Miller Fall Protection does not require the Miller MINILITE Type 2 Fall Arresters to be returned to their factory for annual re-certification. However, the fall arrester must pass the Checklist Inspection in order to be put back into service. If the fall arrester has been involved in a fall or fails the Checklist Inspection, the product must be removed from service immediately. **(All relevant models are shown below)**



Lowering your COST of Ownership

All Miller MINILITE Type 2 Fall Arresters are equipped with inspection Instructions and a Checklist for the product (**see page 2 & 3**). The owner of the unit(s) has the responsibility to inspect the product upon each use in accordance with the instructions provided as well as the guidelines outlined under AS/NZS 1891.4.

- Carefully read the Inspection instructions provided with the MINILITE Fall Arrester.
- Using the MINILITE Fall Arrester Checklist Inspection Sheet, inspect all items listed.
- If all items on the Checklist passes the user's inspection, the fall arrester can be put back into service.
- However, if one or more items on the checklist fails inspection, the fall arrester must be removed from service immediately, and is not to be used again.

Owner inspection of the MINILITE Fall Arresters will reduce the costs of owning the product:

- Saving time and money – if the unit passes the checklist inspection it can be put back into service straight away without causing any interruptions to the working environment.
- Increasing productivity - the owner does not have to send his units back to the manufacturer on an annual basis for servicing (providing the unit passes the checklist inspection) therefore productivity is increased as the units remain in service and operations continue to run smoothly without interferences.

MINILITE Type 2 Fall Arrester Models	
1008587	MINILITE Fall Arrester with Swivel Hook
PFL2.5M-11/AUS	MINILITE Fall Arrester with Triple Acting Karabiners

VISUAL

Checklist Inspection

1. LABEL

- Check the front and back labels on the MINILITE Fall Arrester. Ensure the labels are legible and not torn off or absent

2. HOUSING

- Check the housing on the MINILITE for any cracks or significant deformation.
- Pay particular attention to the area around the installation bracket and all bolts and nuts.
- Fail the unit if there is intense corrosion or pitting is evident

3. FALL INDICATOR

- Check the load indicator located in the lanyard above the snap hook. A label will be exposed when subjected to fall arresting forces.

4. SCREWS

- Check to ensure all screws are present on the unit

5. WEBBING

- Inspection must be performed over the entire length of webbing starting from the snap hook/karabiner end.
- Check if there is any evidence of torn webbing, distortion, excessive wear, or abrasion.
- The unit will fail inspection if any part of the webbing line is damaged

6. ANCHORAGE CONNECTION

- Make sure the anchorage connector is properly seated with the anchor point

FUNCTION

1. LIFELINE RETRACTION & EXTRACTION

- With the device in the mounted position, test the lifeline retraction and tension by pulling out at least a metre of the lifeline and allow it to retract back into the unit. The lifeline should pull out freely and retract all the way back into the unit.
- If the spring appears to be weak, the unit will fail inspection.

2. BRAKING MECHANISMS

- Check that the locking mechanism is functioning properly by tugging on the webbing line which should lock immediately. Pull it a second time to confirm.

3. SNAP HOOK/KARABINER

- Check all parts of the snap hook and/or karabiner (s) for any signs of alterations, distortions, cracks, deep nicks, dents or cuts.

Miller MINILITE

Type 2 Fall Arrester Checklist Inspection



Serial Number:	_____
Date of Manufacture:	_____
Date of Inspection:	_____

VISUAL

1. Label
2. Housing
3. Fall Indicator on Lanyard
4. Screws
5. Webbing
6. Anchorage Connection

PASS	FAIL
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>

FUNCTIONAL

1. Lifeline Retraction & Extraction
2. Braking Mechanism
3. Snap Hook/Karabiner

<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>

If one or more items have failed the Inspection Checklist, the MINILITE Type 2 Fall Arrester must be removed from service immediately. For further assistance please call our customer service centre on **Australia Tel: 1300 139 166 or NZ Tel: 0800 322 200**